
Meridian Administration Tools

Station Administration

User Guide

Document Number: PO833798

Document Release: Standard 4.00

Date: May 1996

© 1995, 1996

All rights reserved

Printed in the United States of America

Information is subject to change without notice. Northern Telecom reserves the right to make changes in design or components as progress in engineering and manufacturing may warrant. This equipment has been tested and found to comply with the limits for a Class A digital device pursuant to Part 15 of the FCC rules, and the radio interference regulations of Industry Canada. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses and can radiate radio frequency energy, and if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at their own expense.

SL-1 and Meridian 1 are trademarks of Northern Telecom.

Revision history

June 1994

Standard, release 1.1.

December 1994

Standard, release 2.0.

January 1996

Standard, release 3.5.

May 1996

Standard, release 4.0.

Contents

Introduction	1
Overview	1
MAT Users	2
Conventions used in this manual	2
 Station Configuration	 5
Overview	5
Station Data Considerations	5
Location	6
DES	6
Sync Status	7
Synchronization Considerations	7
Reports and Text Files	8
Parsing Retrieved Data	8
Multi-Tenant	8
Site Hardware	8
Station configuration window	9
File Menu	10
Edit Menu	11
View Menu	11
Synchronize Menu	12
Accessing Station Data	12
The Station View	13
The Template View	14
New Stations	14

Station Template	14
Add Stations	15
Adding a Single Station	17
Adding Multiple Stations	17
Adding the Stations	19
Deleting Stations	19
Adding a Station Template	20
Station Data Manipulation	21
Updating Stations	22
Station Data	22
Key Assignments	25
Directory Number Assignment	26
Terminal Number Assignment	28
Button Features	29
Administration	32
Designation Strips	35
Designating Directory Numbers	35
Display of Designation Strips	36
Station Data Validation	38
CPND	41
CPND Overview	41
CPND Data Considerations	41
CPND Names vs. Station Names	42
CPND Synchronization	42
The CPND Module	43
CPND File Menu	44
CPND Edit Menu	44
CPND View Menu	45
CPND Synchronize Menu	45
Accessing CPND Data	46
CPND Configuration View	46
CPND Name View	46
Recommended Usage	47

CPND Data Manipulation	47
Updating the Customer Configuration Data	48
Updating the Name Display Data	50
Voice Mailbox	53
Overview	53
VMB Data Considerations	53
VMB Administration	54
Adding/Changing Stations	54
Deleting Stations	55
Changing DN's	56
VMB Data Synchronization	57
Example 1—Deleting Stations	57
Example 2—Adding a Mailbox	57
Example 3—Changing a DN	58
Global Update	59
Overview	59
Selecting Data Items	60
Define Selection Criteria	60
Example Expressions	61
Example Expressions	64
Example 1	64
Example 2	65
Example 3	66
Specify the Change	67
Select the Field to Change	67
Perform the Global Change	69
Change Confirmation	70
Change Completion	70
Global Update—Wildcards, Matching, and Allowed Fields	71
Global Update—Examples	72
Communicating with Meridian 1	75
Overview	75

Communications Considerations	75
The Communications Task	77
Synchronization	77
Download	79
Retrieving All Data	79
Selecting Data to Retrieve	81
Retrieve Since Option	82
Specifying Data to Retrieve	82
Upload	88
Selecting Data to Transmit	88
Synchronization status and Retrieval	88
Synchronization Times	89
Communications Logs	89
Viewing large log files	91
Transmission errors during retrieval	91
Conversion Utility	93
Overview	93
Starting the Conversion Utility	94
File Menu	94
Convert Menu	95
Rebuild File Menu	95
Help Menu	95
Select a MAT Site	96
New Site	96
Open Site	97
Select the STADATA Site	98
Monitor the Conversion Process	99
Generating Reports	101
Overview	101
Reports Considerations	101
Starting the Reports Function	102

File Menu	102
Forms Menu	103
Reports Menu	103
Running Reports	103
Select a Report	103
Select a Destination	105
Print Report	105
View Report	106
Export Report	107
The MAT File Viewer	109
Overview	109
Viewing a File	109
Viewer File Menu	109
Viewer Search Menu	110
Manipulating Viewed Data	111
Browsing the File	111
Save As	111
Display a File Summary	112
Print from the Viewer	113
Search the File	113
Printer Setup	114
Exit the Viewer	114
Designing Report Forms	115
Overview	115
Form Section Concepts	115
The Forms Editor	116
Forms Editor File Menu	117
Forms Editor Edit Menu	117
Forms Editor Section Menu	118
Forms Editor Field Menu	119
Forms Editor Options Menu	120
Forms Editor Fonts Menu	120

Manipulating Sections	121
Insert a Section	121
Define Section Parameters	122
Edit a Form	124
Insert a Field	124
Insert Data Field	125
Insert Calculation Field	125
Insert System Field	126
Dialog Field	126
Edit Field Attributes	128
Edit Text Field Attributes	129
Edit Numeric Field Attributes	130
Edit Date Field Attributes	131
Edit Logical Field Attributes	132
Edit Calculation Field Expression	132
Setting Report Parameters	133
Character Formatting	134
Font Selection	135
Enhancing the Report	135
Include a Bitmap from Disk	136
Report Criteria	136
 Power User Tool	 137
Concepts for the Power User tool	137
Forms and templates	137
Filters	138
Using the power user forms interface	139
Forms interface window buttons	139
Forms interface message bar	139
Keyboard shortcuts	139
Adding a single station or template	140
Updating a single station (or template)	144
Adding multiple stations	144
Validating station data	147
Field validation	147

Station validation	147
Validating the numbering plan and hardware	147
Station fields	151
On-line Help	151
Types of Station field	151
Class of service field	151
Mutli-line keys	152
Single line FTR's	152
Prompts	152
DN and TN fields	152
TN fields	153
DN fields	153
CPND Parameter Fields	156
Designing forms and templates using the forms editor	160
Creating a new form	160
Editing an existing form	162
Feature Groups and MNEMONICS	165
Features and Feature Groups	165
Key Features	174